




CL16QD

Electric pallet-stacking truck

电动托盘堆垛车

Parts list 零件目录

20240531 V01

PARTS ORDERING INSTRUCTIONS

HOW TO ORDER

When you order, supply the part number, quantity, model and serial numbers of your machine. Supplying this information will assure prompt, efficient handing of your order.

Since your dealer carries many parts in stock and maintains up-to-date prices on all parts, he will be able to process your order immediately. If, for some reason, the part is not in stock, he will order it from the factory. In either event, he maintains a current file of service manuals, which give all available parts ordering or technical information.

WHERE TO ORDER

Always order parts from the dealer who sold you your truck. If it is necessary for the dealer to order parts from the factory, he is able to get prompt service for you. Parts are shipped in accordance with shipping instructions given on the order.

INSTRUCTIONS FOR RETURNING PARTS

Under NO CIRCUMSTANCES will parts be accepted at the factory for credit without prior approval. We cannot accept responsibility for parts returned without authorization.

If you have some parts which must be returned, contact your dealer. If he believes parts should be returned, he will arrange for authorization to return the parts.

CHANGES

When changes are made to the machine, revised pages for this manual will be issued. These pages must be inserted in your parts manual as soon as they are received.

Failure to keep your parts manuals up to date will result in confusion and may cause you to order wrong parts.

零件订购说明

如何订购

当您订购的时候，您需要提供叉车零件的编号，数量，型号和序列号。提供这些信息能够保证您的订购更加的高效。

因为您的经销商有很多零件的存货，而且需要保持所有零件的价格是最新的，所以他会尽快地处理您的订购需求。假如因为某些原因，存货中没有这个零件，那么他会从公司订货。无论怎样的情况，他手里都会有一份服务手册文件，它能提供所有可用的零件的订购信息或者技术信息。

订购地点

当您需要订购零件时，请到销售给您叉车的经销商那里订购。如果经销商有必要从公司订购零件，他能为您提供快捷的服务。根据您的订购信息，零件和它对应的操作说明会一起装好。

零件的退还说明

一般情况下，因为信用的关系，退还的零件没有事先的同意，是不会被公司认可的。我们不会对没有经过授权但退还过来的零件负责。

如果您有一些零件一定要退还，请联系您的经销商。若经销商确认零件可以退还，则其会安排授权要退还的零件。

技术修改

当叉车技术有修改时，这本手册的修正页会重新发行。当您拿到这些修正页时，您一定要立即把它们插入到您的零件手册中。若没有及时的更新您的零件手册，则可能会导致您订购、维护等方面的错误。

GENERAL INFORMATION

INDEX

This parts manual is arranged for easy identification of parts .The index at the front of the catalog gives location of major groups and assemblies.

PART LIST

The Item, describes the item on the Figure you are looking at. The Part No. is a numerical description of the item and the part ordering number. The Description is a description of the part number in alphabetical form. The Qty is the quantity used on the machine. The Applied Date is a description when the part is applicable.The Remark is the explanation of the part for a supplement such as the model the capability, the characteristic etc.

HOW TO READ PARTS MANUAL

HELP 1:

Item	Part No	Description	Qty	Applied Date	Remark
------	---------	-------------	-----	--------------	--------

A →

1		02.XDC.3556	Battery	1		24V/20AH
1		02.XDC.3557	Battery	1		24V/30AH
1		02.XDC.3558	Battery	1		24V/40AH
2		03.0132	Screw M5×8	5		

B →

7		03.0245	Nut M12	2		
8		03.04790	Spring	2		
9	01	30.01.6685	Wheel Frame	1	-210125	
9	02	40.11.048	Wheel Frame	1	210125-	

C →

6		02.KSCX.0001	Cover	1		
7		03.0243	Nut M10	2		Cancel
8		40.11.040	Roller	2		
9		03.1088	Bolt M10×60	2		

D →

3		33.054.0001	Frame (550)	1		
3		33.054.0002	Frame (685)	1		
4		03.02393	Screw M6×16	6		
5		40.18.005	Shaft (550)	1		
5		40.15.044	Shaft (685)	1		

E →

6		33.036.0007	Push Rod Welding	2		For 1800Kg
7		03.0691	Bushing Φ19×Φ16×15	4		
8		03.0305	Round Pin Φ5×30	10		

A:The part of Index 1 is Optional.

B:The part of Index 9 has an Applicability, because it's our policy to constantly improve our products.

C:The part of Index 7 indicates that the part is cancelled. Note the version number when ordering.

D:The part of Index 3 indicates that the frame welds have different specifications, 550 or 685 indicates the outer width of the forks. Index 5 indicates the parts used for the outer width of the forks.

E:The part of Index 6 indicates that the part is used for model with load capacity of 1800KG.

1. Record by time

– 210125 : Ending on January 25, 2021.


210125- : Beginning on January 25, 2021.

2. Record by serial number

01 : Ending at 01

02 : Starting at 02

HELP 2:



A:Section 5.2 is the original version.

B:Section 5.201 is the version that some parts in the Section 5.2 have been changed.

C:Section 5.202 is the version that some parts in the Section 5.201 have been changed.

When you order, Please locate specific parts information of your truck by the Applied Date of parts in each version.

概要
目录

将零件目录分组成几个易识别的部分，并把主要结构和总成放置在索引目录中。

零件明细表

Item 描述的是在插图上，您想要找的项目。**Part No.**是零件的一系列描述和它的订购号码。**Description** 是用文字的形式描述零件的号码。**Qty** 代表的是零件在叉车上使用的数量。**Applied Date** 表示的是零件适用的时间范围。**Remark** 是用来补充说明零件信息(例如车型、性能和特征等)。

怎么读取零件明目录

帮助 1:

Item 序号		Part No 代码	Description 名称		Qty 数量	Applied Date 适用日期	Remark 备注
A	➡	1		02. XDC. 3556	Battery 锂电池	1	24V/20AH
		1		02. XDC. 3557	Battery 锂电池	1	24V/30AH
		1		02. XDC. 3558	Battery 锂电池	1	24V/40AH
		2		03. 0132	Screw M5×8 螺钉	5	
B	➡	7		03. 0245	Nut M12 螺母	2	
		8		03. 04790	Spring 弹簧	2	
		9	01	30. 01. 6685	Wheel Frame 轮架	1	-210125
		9	02	40. 11. 048	Wheel Frame 轮架	1	210125-
C	➡	6		02. KSCX. 0001	Cover 前盖板	1	
		7		03. 0243	Nut M10 螺母	2	Cancel/取消
		8		40. 11. 040	Roller 滚子	2	
		9		03. 1088	Bolt M10×60 螺栓	2	
D	➡	3		33. 054. 0001	Frame (550) 车架	1	
		3		33. 054. 0002	Frame (685) 车架	1	
		4		03. 02393	Screw M6×16 螺钉	6	
		5		40. 18. 005	Shaft (550) 支撑轴	1	
		5		40. 15. 044	Shaft (685) 支撑轴	1	
E	➡	6		33. 036. 0007	Push Rod Welding 推杆	2	For 1800Kg
		7		03. 0691	BushingΦ19×Φ16×15 复合套	4	
		8		03. 0305	Round PinΦ5×30 弹性圆柱销	10	

A: 序号 1 表示该零件有几个品种可供您的选择。

B: 序号 9 表示该零件有一个适用的时间范围。这是因为我们在不断地进行产品的升级。

C: 序号 7 表示该零件取消，订购时注意版本号。

D: 序号 3 表示车架焊接体有不同的规格，550 或 685 表示货叉的外宽。序号 5 表示配用于货叉外宽的零部件。

E: 序号 6 表示该零件配用载重 1800KG 车型。

1. 用时间记录

– **210125** : 截止到 2021 年 01 月 25 日


210125- : 起始于 2021 年 01 月 25 日

2. 用序列号记录

01 : 截止序列号 01

02 : 起始序列号 02

帮助 2:



A: 章节 5.2 表示原始版本；
B: 章节 5.201 表示在原始版本（章节 5.2）上零件有所变更；
C: 章节 5.202 表示在变更版本（章节 5.201）上零件有所变更。
当您订购零件时，请根据每个版本中零件的适用时间来判断您所选购车型的零件信息。

Index 目录

1.Frame System 车身系统

1.1 Distribution Box Components 配电箱组件	1
1.2 Cover Assembly 外罩总成	2
1.3 Protective Arm Assembly 防护臂组件	3
1.4 Steering Wheel Assembly 转向轮组件	4
1.5 Pedal Assembly 踏板总成	5

2.Driving System 驱动系统

2.1 Driving System 驱动系统	6
2.2 Driving Assembly 驱动总成	7

3.Operating System 操作系统

3.1 Operating Handle Assembly 操作手柄组件	9
3.2 Handle Head Assembly 手柄头总成	10

4.Hydraulic System 液压系统

4.1 Hydraulic System 液压系统	12
4.2 Power Unit Assembly 动力单元组件	13

5.Lifting System 起升系统

5.1 Lifting System 起升系统.....14

5.2 Outer Portal Frame Assembly 外门架组件.....15

5.3 Middle Portal Frame Assembly 中门架组件..... 17

5.4 Inside Portal Frame Assembly 内门架组件..... 18

5.5 Fork Holder Assembly 货叉架组件..... 19

6.Electric System 电气系统


6.1 Electrical Assembly 电气总成..... 20

6.2 Control Line Assembly 控制线总成.....21

6.3 Power Line Assembly 动力线总成..... 22

修订记录


版 本	修订人	修订事项
20240531 V01	冯远	首次发布；

1.1 Distribution Box Components 配电箱组件							
		Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
		1	20303010065	Operating Handle Assembly 操作手柄组件	1		82.02.145
		2	54307000001	Dust Cover 防尘罩	1		02.01.2134
		3	30251060028	Screw M6×20 螺钉	4		03.0088
		4	20102010915	Distribution Box 配电箱	1		
		5	30421680001	Retaining Ring 挡圈	1		03.0035
		6	54303000012	Nylon Sleeve 尼龙套	1		02.01.21170
		7	20203000456	Fixed Block 固定座	1		30.01.1292
		8	20103010159	Steering Axle 转向轴	1		33.008.0002
		9	30201100018	Screw M10×25 螺钉	2		03.1051
		10	20301010002	Steering Sensor 转向传感器	1		81.004.033
		11	30401080001	Flat Washer 8 平垫	4		03.0050
		12	30411080002	Elastic Washer 8 弹垫	4		03.0012
		13	30201080005	Screw M8×25 螺钉	4		03.01560
		14	51231000011	Balance Wheel Assembly 平衡轮组件	2		81.003.011
		15	30401100002	Flat Washer 10 平垫	8		03.00513
		16	30411100002	Elastic Washer 10 弹垫	8		03.0014
		17	30201100028	Screw M10×35 螺钉	8		03.0182

1.2


Cover Assembly

外罩总成



Item	Part No.	Description	Qty	Applied Date	Remark
序号	代码	名称	数量	适用日期	备注
1	54302000104	Cover面罩	1		02. FGJ. 0239
2	30251060020	Screw M6×16螺钉	6		03. 0101
3	54302000073	Battery Cover电瓶盖板	1		02. FGJ. 0189


1.2 Protective Arm Assembly 防护臂组件




Item 序号	Part No. 代码	Description 名称		Qty 数量	Applied Date 适用日期	Remark 备注
A	55202000006	Protective Arm Assembly	防护臂组件	1		
1	55202000005	Arm Guard Right	护臂架右	1		30. 01. 1478
2	55202000004	Arm Guard Left	护臂架左	1		30. 01. 1477
3	30501100003	Cylindrical Pin	圆柱销	2		03. 0438
4	54307000009	Dust Ring	防尘圈	2		
5	30421480001	Retaining Ring	挡圈	2		03. 0072
6	50301485001	Gasket	垫片	2		30. 01. 1203
7	40311510001	Bushing	衬套	2		03. 0503
8	30201050009	Screw M5×12	螺钉	4		03. 0131
9	30411050001	Elastic Washer 5	弹垫	4		03. 00132
10	30401050001	Flat Washer 5	平垫	4		03. 00511
11	30401050001	Switch board left	开关板左	1		03. 00511
12	70103000005	Microswitch	微动开关	2		02. 01. 2178
13	30401050001	Screw	螺钉	4		03. 00511
14	30101100002	Bolt M10×30	螺栓	4		30. 35. 0297
15	30411100002	Elastic Washer 10	弹垫	4		03. 0014
16	30401100002	Flat Washer 10	平垫	4		03. 00513
17	55204000031	Arm guard seat	护臂座	1		
18	55204000028	Left Axis Of Rotation	转轴左	1		
19	30221080003	Screw M8×12	螺钉	6		
20	55204000029	Right Axis Of Rotation	转轴右	1		
21	30311100001	Nut M10	螺母	8		03. 0243
22	55204000012	Arm Guard Connecting Plate	护臂连接板	2		30. 01. 1147
23	30111100001	Bolt M10×35	螺栓	8		03. 0205

1.3 Steering Wheel Assembly

转向轮组件

[illegible]


1.4 Pedal Assembly
踏板总成

[illegible]

2.1


Driving System

驱动系统




Item	Part No.	Description	Qty	Applied Date	Remark
序号	代码	名称	数量	适用日期	备注
1	52101000039	Driving Assembly 驱动总成	1		02.QD.01.0007
2	30201120003	Screw M12×35 螺钉	4		03.01721
3	30251140006	Screw M14×35 螺钉	4		03.00942

2.2 Driving Assembly 驱动总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	52101000039	Driving Assembly 驱动总成	1		02.QD. 01.0007
1	30201080007	Screw M8×40 螺钉	10		03.01590
2	50301090002	Washers 垫圈	4		30.11.0002
3	40321300002	Dust Ring 防尘圈	4		03.0487
4	50301320001	Guiding Ring 导向环	2		03.0501
5	20201000470	Upper Bracket 上支架	1		30.01.1135
6	20201000001	Sliding Rod 滑动杆	2		30.01.0189
7	50401000044	Spring 弹簧	2		02.01.2112
8	30421400002	Hole Retaining Rings 孔用挡圈	2		03.0027
9	40502330001	Sealing Ring 密封圈	4		03.0488
10	20201000459	Shaft Sleeve 轴套	2		30.01.1129
11	50301270001	Guiding Ring 导向环	2		03.0502
12	20201000466	Lower Bracket 下支架	1		30.01.1133
13	30201080005	Screw M8×25 螺钉	6		03.01560
14	30201060010	Screw M6×150 螺钉	2		03.0178
15	30411060002	Elastic Washer 6 弹垫	5		03.0011
16	55704000007	Brakes 制动器	1		02.01.0053
17	70401000006	Electrical Machinery 电机	1		02.DJ. 0081
18	30602040001	Semicircle Key 半圆键	1		
19	52202200001	Small Helical Gear 小斜齿轮	1		02.01.0318
20	30311120001	Nut M12 螺母	1		03.0820
21	30201080032	Screw M8×35 螺钉	12		03.0158
22	20201000511	Installation Sleeve 安装套	1		30.01.1565
23	70109000000	Proximity Switch 接近开关	1		19.034653
24	20201000978	Drive Base 驱动底座	1		
25	30201060018	Screw M6×12 螺钉	1		03.0145
26	70309000009	Encoder 编码器	1		02.BMQ. 2138
27	73109000014	Small Magnetic Head 小磁头	1		02.01.2152
28	70402000001	Electrical Machinery 电机	1		02.DJ. 2102

2.2 Driving Assembly 驱动总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
29	30201080006	Screw M8×30 螺钉	4		03.01571
30	30411080002	Elastic Washer 8 弹垫	28		03.0012
31	52105000053	Pinion 小齿轮	1		
32	30401060006	Large washer 6 大垫圈	1		03.0644
33	30201060020	Screw M6×16 螺钉	1		03.0147
34	30711160001	Bearing 轴承	1		02.01.0071
35	30211040019	Screw M4×10 螺钉	3		03.04170
36	20201000508	Induction Strip 感应条	1		
37	52105000024	Big Gear 大齿轮	1		02.01.9084
38	50205200001	Nut M20×1.5 螺帽	1		02.01.9090
39	52105000043	Large Helical Gear 大斜齿轮	1		02.01.9081
40	30702025001	Bearing 轴承	1		03.90.035
41	30251080012	Screw M8×16 螺钉	8		03.0117
42	50204140003	Oil Plug 油塞	1		02.01.9089
43	30803014001	Sealing Gasket 密封垫	1		03.0482
44	52105000019	Shell Cover 壳体盖	1		02.01.9079
45	52105000034	Sealing Ring 密封圈	1		02.01.9091
46	52105000050	Gearbox 齿轮箱体	1		
47	30601080003	Flat Key 平键	1		02.01.9087
48	50203300001	Nut M30×1.5 螺母	1		02.01.00801
49	52105000020	Arc Tooth Set 弧齿组	1		02.01.9080
50	30702060001	Bearing 轴承	1		03.90.060
51	30702050003	Bearing 轴承	1		03.90.059
52	30802065002	Oil Seals 油封	1		02.01.9086
53	52105000023	Output Shaft 输出轴	1		02.01.9083
54	30351140001	Nut 螺母	5		03.02020
55	51241000021	Wheel 轮子	1		02.LZ.0121

3.1 Operating Handle Assembly 操作手柄组件

[illegible]


3.2 Handle Head Assembly 手柄头总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	71501000001	Handle head assembly 手柄头总成	1		02. SB. 317515
1	71511000015	Belly Switch 肚皮开关	1		16. 0038
2	71511000016	Spring 弹簧	1		03. 0725
3	71511000001	Upper Cover 上盖	1		02. 01. 31770
4	71511000014	Button Plug 按钮堵头	4		02. 01. 317725
5	70103000006	Micro Switch 微动开关	7		
6	71511000007	Lift Button Base 升降按钮底座	2		02. 01. 317718
7	71511000004	Lift Button 升降按钮	2		02. 01. 317721
8	71511000017	Cylindrical Pin $\Phi 3 \times 17$ 圆柱销	2		03. 0760
9	73109000011	Fixing Sleeve 固定套	2		30. 01. 3427
10	71511000018	Spring 弹簧	3		03. 0726
11	71511000005	Horn Button 喇叭按钮	1		02. 01. 317723
12	71511000345	Button Clip 按钮卡子	2		02. 01. 317724
13	30231030002	Screw 螺钉	5		02. SB. PJ. 0012
14	71511000107	Install The Card 安装卡	1		02. SB. PJ. 0006
15	70132000105	Accelerator Assembly 加速器总成	1		02. 01. 2155
16	71511000115	Knob 旋钮	2		02. SB. PJ. 0027
17	71511000013	Bracket Right 支架右	1		30. 01. 3424
18	70132000001	Accelerator 加速器	1		02. 01. 2151
19	30431080001	Wave Washers 波形垫圈	2		03. 0735
20	71511000012	Bracket Left 支架左	1		30. 01. 3423
21	71511000112	Shaft Sleeve 轴外套	2		30. 01. 3426
22	71511000113	Shaft Jacket 轴外套	2		02. SB. PJ. 0025
23	30211030008	Screw M3 $\times$ 12 螺钉	2		03. 05364
24	30201050009	Screw M5 $\times$ 12 螺钉	2		03. 0131
25	71511000002	Lower Cover 下盖	1		02. 01. 31772
26	30201050017	Screw M5 $\times$ 25 螺钉	2		03. 01410
27	30201050019	Screw M5 $\times$ 55 螺钉	2		03. 0751

3.2 Handle Head Assembly

手柄头总成


[illegible]

4.1 Hydraulic System 液压系统



Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	40301500032	Middle Oil Cylinder 中油缸	1		02. YG. 20283
2	30401100002	Flat Washer 10 平垫	4		03. 00513
3	30411100002	Elastic Washer 10 弹垫	6		03. 0014
4	30101100002	Bolt M10×30 螺栓	2		30. 35. 0297
5	30201100022	Screw M10×20 螺钉	2		03. 0163
6	20202000010	Installation Block 安装块	1		30. 08. 0001
7	30201100025	Screw M10×40 螺钉	2		03. 0168
8	40401024060	Power Unit 动力单元	1		02. DLDY. 0166
9	40101160245	High-Pressure Hoses 高压胶管	1		
10	40405000024	Explosion Proof Valve 防爆阀	2		02. 01. 30480
11	30803016001	Sealing Gasket 密封垫	3		03. 0483
12	40201160009	Straight Connector 直通接头	1		02. 01. 3013
13	40121000092	Steel Pipe 钢管	1		02. YYL. 3021
14	30401120001	Flat Washer 12 平垫	2		03. 00514
15	30411120003	Elastic Washer 12 弹垫	6		03. 0015
16	30201120003	Screw M12×35 螺钉	6		03. 01721
17	40301450011	Lifting Oil Cylinder 起升油缸	2		02. YG. 20282
18	40201160012	Direct Head 直接头	2		02. 01. 3051
19	40122000091	Steel Pipe 钢管	1		02. YYL. 30190
20	40202160010	Right Angle Joint 直角接头	1		02. 01. 3102
21	40101160020	High-Pressure Hoses 高压胶管	1		
22	40201160015	Straight Connector 直通接头	1		02. 01. 3084
23	40205000008	Tee Connector 三通接头	1		02. 01. 3014
24	40121000461	Steel Pipe 钢管	1		


4.2 Power Unit Assembly
动力单元组件




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	40401024060	Power Unit 动力单元	1		02.DLDY.0166
1	54012000018	Hoop 抱箍	1		03.1207
2	70402000025	Electrical Machinery 电机	1		02.DJ.210401
3	20102030023	Connection Line 连接线	1		
4	54312000003	Pipe Sheath 烟斗护套	2		02.01.2265
5	70303000006	Contactor 接触器	1		02.01.2207
6	40411000083	Coupling 联轴器	1		
7	40405000040	Overflow Valve 溢流阀	1		02.01.9029
8	40407000002	Center Block 中心块	1		
9	30201060025	Screw M6×35 螺钉	4		03.0176
10	40405000038	One-Way Valve 单向阀	1		02.01.9028
11	71531000002	Solenoid Valve 电磁阀	1		02.01.9034
12	71531000031	Electromagnetic Valve Coil 电磁阀线圈	1		02.01.9366
13	40405000050	Pressure Compensation Valve 压力补偿阀	1		02.01.9035
14	30803013001	Gaskets 密封垫	1		03.1067
15	50204000003	Plugs 堵头	1		02.01.9056
16	40411000077	Return Pipe 回油管	2		
17	30801110003	O-Rings O型圈	1		02.01.0338
18	40402000005	Gear Pumps 齿轮泵	1		02.01.0024
19	30201080040	Screw M8×80 螺钉	2		03.0877
20	40411000045	Suction Tube 吸油管	1		02.DLDY.SJ.045
21	40412000010	Strainer 滤网	1		02.01.9051
22	40410000010	Nut M8 螺母	4		02.01.30423
23	40410000010	Fuel Tank Cap 油箱盖	1		02.01.30423
24	40408000010	Fuel Tank 油箱	1		30.01.1265
25	30803018001	Gaskets 密封垫	1		03.0484
26	50204180001	Screw Plugs 螺塞	1		03.0989

5.1 Lifting System

起升系统


[illegible]

6.2 Outer Portal Frame Assembly 外门架组件



Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	20102010918	Outer Portal frame (570) 外门架	1		
1	20102010582	Outer Portal frame (695) 外门架	1		33.027.0005
2	30421350001	Retaining Ring 挡圈	2		03.0583
3	51103000025	Dust Ring 防尘片	2		02.01.30682
4	51102000001	Roller 滚轮	2		02.01.3071
5	51103000024	Support Components 支架组件	2		02.01.30681
6	51103000023	Locking Pad 止松片	2		
7	51103000022	Regulating Screw 调节螺丝	2		02.01.30683
8	30201080005	Screw M8×25 螺钉	1		03.01560
9	30411080002	Elastic Washer 8 弹垫	5		03.0012
10	20202001679	Steel Pipe Clamp 钢管夹	1		
11	30201080004	Screw M8×20 螺钉	4		03.01550
12	30401080001	Flat Washer 8 平垫	4		03.0050
13	20202001677	Cylinder Fastening 油缸紧固夹	2		
14	20202001678	Tighten The Cushion Block 紧固夹垫板	2		
15	54101000035	R-shaped clamp R型箍	2		03.04615
16	30411060002	Elastic Washer 6 弹垫	2		03.0011
17	30201060018	Screw M6×12 螺钉	2		03.0145
18	54314000073	Protective Barrier 防护挡板	1		02.FHDB.02291
19	30251160006	Screw M16×52 螺钉 M16×52	2		03.00984
20	30311160001	Nut M16 螺母	8		03.0247
21	30211060008	Screw M6×16 螺钉	6		03.0228
22	30251160014	Screw M16×38 螺钉 M16×38	2		03.00981
23	30401160002	Flat Washer 16 平垫	6		03.0047
24	30411160002	Elastic Washer 16 弹垫	6		03.0017
25	30101160020	Screw M16×80 螺钉	4		03.0390
26	51241000019	Wheel 轮子	4		02.LZ.0119
27	30701020007	Bearing 轴承	8		03.90.057
28	50101200040	Front Wheel Axle 前轮轴	4		30.01.3459

5.2	Outer Portal Frame Assembly 外门架组件
-----	--------------------------------------

[illegible]


5.3

Middle Portal Frame Assembly

中门架组件


Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	51103000022	Regulating Screw 调节螺丝	4		02. 01. 30683
2	51103000023	Locking Pad 止松片	4		
3	51103000024	Support Components 支架组件	4		02. 01. 30681
4	51102000001	Roller 滚轮	4		02. 01. 3071
5	51103000025	Dust Ring 防尘片	4		02. 01. 30682
6	30421350001	Retaining Ring 挡圈	4		03. 0583
7	20102010574	Middle Portal Frame 中门架	1		33. 027. 0004
8	30421300001	Retaining Ring 挡圈	4		03. 0068
9	50101300010	Sprocket Shaft 链轮轴	2		30. 01. 1142
10	30701030004	Bearing 轴承	4		03. 90. 017
11	51106000002	Sprocket 链轮	2		30. 01. 03311
12	20102010573	Pulley Frame 滑轮架	1		33. 027. 0003
13	30401080001	Flat Washer 8 平垫	2		03. 0050
14	30411080002	Elastic Washer 8 弹垫	2		03. 0012
15	30201080004	Screw M8×20 螺钉	2		03. 01550
16	51107000011	Pulley 滑轮	1		30. 01. 1453
17	30421200001	Retaining Ring 挡圈	1		03. 0064

5.4 Inside Portal Frame Assembly
内门架组件


[illegible]

5.5 Fork Holder Assembly

托盘架


[illegible]

6.1 Electrical System 电气总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	70601000006	Fuel Gauge 电量表	1		
2	70105000001	Key Switches 钥匙开关	1		02. 01. 2186
3	30201050011	Screw M5×16 螺钉	4		03. 0133
4	30411050001	Elastic Washer 5 弹垫	6		03. 00132
5	30401050001	Flat Washer 5 平垫	4		03. 00511
6	20202000762	Switch Mounts 开关安装架	2		
7	70109000000	Proximity Switches 接近开关	2		19. 034653
8	30211030004	Screw M3×16 螺钉	4		03. 05360
9	30211040011	Screw M4×25 螺钉	2		03. 0223
10	70103000001	Microswitch 微动开关	1		02. 01. 2182
11	70501240013	Lead-Acid Battery 铅酸电池	1		02. XDC. 2194
12	30211050016	Screw M5×10 螺钉	2		03. 0219
13	70104000005	Emergency Stop Switch 急停开关	1		
14	70331000412	Electric Control Board 电控板	1		20202001692
15	70302000011	Steering Controller 转向控制器	1		02. KZQ. 2369
16	30201040011	Screw M4×30 螺钉	2		03. 0125
17	70222000002	Horn 喇叭	1		02. 01. 2218
18	30401080001	Flat Washer 8 平垫	4		03. 0050
19	30411080002	Elastic Washer 8 弹垫	4		03. 0012
20	30201080004	Screw M8×20 螺钉	4		03. 01550
21	70301000011	Control Board Assembly 控制板总成	1		

6.2 Control Line Assembly

[illegible]

6.3	Power Line Assembly 动力线总成
-----	------------------------------

[illegible]

本零件目录最终由制造商保留解释权!

The power of interpretation of this part catalogue will be preserved by the manufacturer eventually!