




EGS18L
Counterbalance lift truck
平衡重式叉车
Parts list 零件目录

20240725 V01

PARTS ORDERING INSTRUCTIONS

HOW TO ORDER

When you order, supply the part number, quantity, model and serial numbers of your machine. Supplying this information will assure prompt, efficient handing of your order.

Since your dealer carries many parts in stock and maintains up-to-date prices on all parts, he will be able to process your order immediately. If, for some reason, the part is not in stock, he will order it from the factory. In either event, he maintains a current file of service manuals, which give all available parts ordering or technical information.

WHERE TO ORDER

Always order parts from the dealer who sold you your truck. If it is necessary for the dealer to order parts from the factory, he is able to get prompt service for you. Parts are shipped in accordance with shipping instructions given on the order.

INSTRUCTIONS FOR RETURNING PARTS

Under NO CIRCUMSTANCES will parts be accepted at the factory for credit without prior approval. We cannot accept responsibility for parts returned without authorization.

If you have some parts which must be returned, contact your dealer. If he believes parts should be returned, he will arrange for authorization to return the parts.

CHANGES

When changes are made to the machine, revised pages for this manual will be issued. These pages must be inserted in your parts manual as soon as they are received.

Failure to keep your parts manuals up to date will result in confusion and may cause you to order wrong parts.

零件订购说明

如何订购

当您订购的时候，您需要提供叉车零件的编号，数量，型号和序列号。提供这些信息能够保证您的订购更加的高效。

因为您的经销商有很多零件的存货，而且需要保持所有零件的价格是最新的，所以他会尽快地处理您的订购需求。假如因为某些原因，存货中没有这个零件，那么他会从公司订货。无论怎样的情况，他手里都会有一份服务手册文件，它能提供所有可用的零件的订购信息或者技术信息。

订购地点

当您需要订购零件时，请到销售给您叉车的经销商那里订购。如果经销商有必要从公司订购零件，他能为您提供快捷的服务。根据您的订购信息，零件和它对应的操作说明会一起装好。

零件的退还说明

一般情况下，因为信用的关系，退还的零件没有事先的同意，是不会被公司认可的。我们不会对没有经过授权但退还过来的零件负责。

如果您有一些零件一定要退还，请联系您的经销商。若经销商确认零件可以退还，则其会安排授权要退还的零件。

技术修改

当叉车技术有修改时，这本手册的修正页会重新发行。当您拿到这些修正页时，您一定要立即把它们插入到您的零件手册中。若没有及时的更新您的零件手册，则可能会导致您订购、维护等方面的错误。

GENERAL INFORMATION

INDEX

This parts manual is arranged for easy identification of parts .The index at the front of the catalog gives location of major groups and assemblies.

PART LIST

The Item, describes the item on the Figure you are looking at. The Part No. is a numerical description of the item and the part ordering number. The Description is a description of the part number in alphabetical form. The Qty is the quantity used on the machine. The Applied Date is a description when the part is applicable.The Remark is the explanation of the part for a supplement such as the model the capability, the characteristic etc.

HOW TO READ PARTS MANUAL

HELP 1:

Item	Part No	Description	Qty	Applied Date	Remark
------	---------	-------------	-----	--------------	--------

A →

1		02.XDC.3556	Battery	1		24V/20AH
1		02.XDC.3557	Battery	1		24V/30AH
1		02.XDC.3558	Battery	1		24V/40AH
2		03.0132	Screw M5×8	5		

B →

7		03.0245	Nut M12	2		
8		03.04790	Spring	2		
9	01	30.01.6685	Wheel Frame	1	-210125	
9	02	40.11.048	Wheel Frame	1	210125-	

C →

6		02.KSCX.0001	Cover	1		
7		03.0243	Nut M10	2		Cancel
8		40.11.040	Roller	2		
9		03.1088	Bolt M10×60	2		

D →

3		33.054.0001	Frame (550)	1		
3		33.054.0002	Frame (685)	1		
4		03.02393	Screw M6×16	6		
5		40.18.005	Shaft (550)	1		
5		40.15.044	Shaft (685)	1		

E →

6		33.036.0007	Push Rod Welding	2		For 1800Kg
7		03.0691	Bushing Φ19×Φ16×15	4		
8		03.0305	Round Pin Φ5×30	10		

A:The part of Index 1 is Optional.

B:The part of Index 9 has an Applicability, because it's our policy to constantly improve our products.

C:The part of Index 7 indicates that the part is canceled. Note the version number when ordering.

D:The part of Index 3 indicates that the frame welds have different specifications, 550 or 685 indicates the outer width of the forks. Index 5 indicates the parts used for the outer width of the forks.

E:The part of Index 6 indicates that the part is used for model with load capacity of 1800KG.

1. Record by time

– 210125 : Ending on January 25, 2021.


210125- : Beginning on January 25, 2021.

2. Record by serial number

01 : Ending at 01

02 : Starting at 02

HELP 2:



A:Section 5.2 is the original version.

B:Section 5.201 is the version that some parts in the Section 5.2 have been changed.

C:Section 5.202 is the version that some parts in the Section 5.201 have been changed.

When you order, Please locate specific parts information of your truck by the Applied Date of parts in each version.

概要
目录

将零件目录分组成几个易识别的部分，并把主要结构和总成放置在索引目录中。

零件明细表

Item 描述的是在插图上，您想要找的项目。**Part No.**是零件的一系列描述和它的订购号码。**Description** 是用文字的形式描述零件的号码。**Qty** 代表的是零件在叉车上使用的数量。**Applied Date** 表示的是零件适用的时间范围。**Remark** 是用来补充说明零件信息(例如车型、性能和特征等)。

怎么读取零件明目录

帮助 1:

Item 序号		Part No 代码	Description 名称		Qty 数量	Applied Date 适用日期	Remark 备注
A	1	02.XDC.3556	Battery	锂电池	1		24V/20AH
	1	02.XDC.3557	Battery	锂电池	1		24V/30AH
	1	02.XDC.3558	Battery	锂电池	1		24V/40AH
	2	03.0132	Screw M5×8	螺钉	5		
B	7	03.0245	Nut M12	螺母	2		
	8	03.04790	Spring	弹簧	2		
	9	01 30.01.6685	Wheel Frame	轮架	1	-210125	
	9	02 40.11.048	Wheel Frame	轮架	1	210125-	
C	6	02.KSCX.0001	Cover	前盖板	1		
	7	03.0243	Nut M10	螺母	2		Cancel/取消
	8	40.11.040	Roller	滚子	2		
	9	03.1088	Bolt M10×60	螺栓	2		
D	3	33.054.0001	Frame(550)	车架	1		
	3	33.054.0002	Frame(685)	车架	1		
	4	03.02393	Screw M6×16	螺钉	6		
	5	40.18.005	Shaft(550)	支撑轴	1		
	5	40.15.044	Shaft(685)	支撑轴	1		
E	6	33.036.0007	Push Rod Welding	推杆	2		For 1800Kg
	7	03.0691	BushingΦ19×Φ16×15	复合套	4		
	8	03.0305	Round PinΦ5×30	弹性圆柱销	10		

A: 序号 1 表示该零件有几个品种可供您的选择。

B: 序号 9 表示该零件有一个适用的时间范围。这是因为我们在不断地进行产品的升级。

C: 序号 7 表示该零件取消，订购时注意版本号。

D: 序号 3 表示车架焊接体有不同的规格，550 或 685 表示货叉的外宽。序号 5 表示配用于货叉外宽的零部件。

E: 序号 6 表示该零件配用载重 1800KG 车型。

1. 用时间记录

– **210125** : 截止到 2021 年 01 月 25 日


210125- : 起始于 2021 年 01 月 25 日

2. 用序列号记录

01 : 截止序列号 01

02 : 起始序列号 02

帮助 2:



A: 章节 5.2 表示原始版本;

B: 章节 5.201 表示在原始版本 (章节 5.2) 上零件有所变更;

C: 章节 5.202 表示在变更版本 (章节 5.201) 上零件有所变更。

当您订购零件时, 请根据每个版本中零件的适用时间来判断您所选购车型的零件信息。

Index 目录

1. Frame System 车身系统

1.1 Frame Assembly 车架总成.....	1
1.2 Cover Assembly 覆盖件组件.....	3
1.3 Overhead Guard Assembly 护顶架总成.....	4

2. Drive System 驱动系统

2.1 Drive Assembly 驱动总成.....	5
------------------------------	---

3. Mast Lifting System 起升系统

3.1 Third Level Fully Free Gantry Assembly (With Side Shift) 三级全自由门架总成（带侧移）	6
3.2 Tray Rack Assembly (With Side Shift) 托盘架总成（带侧移）	9

4. Hydraulic System 液压系统

4.1 Body Hydraulic System 车身液压系统.....	10
4.2 Three Stage Gantry Hydraulic System 三级门架液压系统.....	12
4.3 Three Stage Gantry Side Shift Hydraulic System 侧移液压系统.....	13

5. Electric System 电气系统


5.1 Electric Assembly 电气总成.....	14
5.2 Control Board Assembly 控制板总成.....	16

5.3 Wiring Harness 线束总成.....	17
5.4 Cable Assembly 电缆总成.....	18

修订记录


版 本	修订人	修订事项
20240725 V01	祝垠	首次发布；

1.1 Frame Assembly
车架总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	54316000010	Foot Pad 脚垫	1		30.51.0021
2	30201080007	Screw M8×40 螺钉	4		03.01590
3	20104010201	Pedal 脚踏板	1		33.042.0009
4	54316000013	Shock Pad 减震垫	4		30.51.0022
5	30201060037	Screw M6×16 螺钉	2		03.0934
6	20204000009	Installation Board 安装板	1		30.51.0003
7	20104010193	Frame 车架	1		33.042.0001
8	30201080003	Screw M8×16 螺钉	3		03.01530
9	30411080002	Spring Washer Φ8 弹垫	5		03.0012
10	54410000005	Back 靠背	1		82.55.0014
11	30221120004	Screw M12×16 紧定螺钉	4		03.0854
12	20104010200	Left Battery Baffle 电瓶左挡板	2		33.042.0008
13	20202000533	Side Pressure Block 侧压块	2		40.31.164
14	51108000008	Roller 辊筒	8		30.01.6610
15	30111140004	Bolt M14×1.5×30 螺栓	10		03.0980
16	51210000010	Front Wheel 前轮	2		02.LZ.0293
17	20104010213	Rotation Shaft 转轴	2		33.042.0018
18	30701045002	Bearing 6209 轴承	2		03.90.039
19	20104010206	Flange Sleeve 法兰套	2		33.042.0017
20	30701040003	Bearing 6208 轴承	2		03.90.030
21	30431350001	Tab Washer 35 止动垫圈	2		03.0525
22	30331350002	Nut M35×1.5 圆螺母	2		03.0291
23	20204000074	Dust Cover 防尘盖	2		30.51.0026
24	30201040012	Screw M4×6 螺钉	6		03.0127
25	30101120036	Bolt M12×50 螺栓	12		03.0387
26	30411120003	Spring Washer Φ12 弹垫	12		03.0015
27	30401120001	Flat Washer Φ12 平垫	12		03.00514
28	30101140007	Bolt M14×50 螺栓	4		03.0780


1.1 Frame Assembly

[illegible]


1.2 Cover Assembly

[illegible]

1.3 Overhead Guard Assembly 护顶架总成


[illegible]

2.1 Drive Assembly
驱动总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	20304010197	Drive Assembly 驱动总成	1		82.55.0009
1	30201080006	Screw M8×30 螺钉	4		03.01571
2	30411080002	Spring Washer Φ8 弹垫	11		03.0012
3	70402000005	Dc Steering Motor 直流转向电机	1		02.DJ.2109
4	70109000000	Proximity Switch 接近开关	1		19.034653
5	30211040006	Screw M4×12 螺钉	2		03.0215
6	20203000664	Mounting Sleeve 安装套	1		57700001060
7	30201120015	Screw M12×50 螺钉	6		03.0189
8	30411120003	Spring Washer Φ12 弹垫	6		03.0015
9	30101160024	Bolt M16×70 螺栓	5		03.0395
10	30411160002	Spring Washer Φ16 弹垫	5		03.0017
11	30401160002	Flat Washer Φ16 平垫	5		03.0047
12	20204000086	Drive Base Plate 驱动底板	1		30.51.0030
13	55704000005	Electromagnetic Brake 电磁制动器	1		02.01.00532
14	30201080007	Screw M8×40 螺钉	6		03.01590
15	30401080001	Flat Washer Φ8 平垫	6		03.0050
16	70401000015	Ac Motor 48V 6Kw 交流电机	1		02.DJ.00834
17	30251060028	Screw M6×20 螺钉	3		03.0088
18	20203000822	Induction Strip 感应条	1		30.05.276
19	52102000002	Gearbox 变速箱	1		02.01.9166
20	51241000097	Wheel 轮子	1		02.QDL.0069
21	30201080004	Screw M8×20 螺钉	1		03.01550
22	50301090001	Large Washer 大垫圈	1		30.05.277

3.1 Third Level Fully Free Gantry Assembly (With Side Shift) 三级全自由门架总成（带侧移）




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	30101160021	Bolt M16×90 螺栓	2		03.0391
2	51107000006	Oil Pipe Pulley 油管滑轮	2		30.05.181
3	20204001142	Spacer Sleeve 隔套	1		
4	20104010254	Support 轮架	1		
5	30411160002	Spring Washer Φ16 弹垫	5		03.0017
6	30301160002	Nut M16 螺母	9		03.0260
7	30101080004	Bolt M8×16 螺栓	4		30.35.0299
8	30411080002	Spring Washer Φ8 弹垫	5		03.0012
9	30401080001	Flat Washer Φ8 平垫	5		03.0050
10	30101100004	Bolt M8×16 螺栓	3		30.35.0300
11	30411100002	Spring Washer Φ10 弹垫	7		03.0014
12	30401100002	Flat Washer Φ10 平垫	7		03.00513
13	20204001007	Floor 底板	1		30.25.0231
14	20204000636	Top Seat 顶座	1		30.01.6417
15	51106000003	Chain Wheel Φ90 链轮	4		30.05.180
16	30421350001	Ring 35 挡圈	4		03.0583
17	53101000051	Chain B (4800) 链条 B (4800)	2		02.LT.3494
17	53101000076	Chain B (5500) 链条 B (5500)	2		
18	20104010249	In Mast (4800) 内门架 (4800)	1		
18	20104010252	In Mast (5500) 内门架 (5500)	1		
19	30101080023	Bolt M8×40 螺栓	1		03.0358
20	50301165003	Shaft Sleeve Φ26×Φ16.5 轴套	1		30.05.001
21	30101160035	Bolt M16×1.5×70 螺栓	2		03.0941
22	30401160002	Flat Washer Φ16 平垫	2		03.0047
23	20202000432	Plug Screw M36 调整螺栓	2		30.33.0051
24	20104010248	Middle Door Frame (4800) 中门架 (4800)	1		
24	20104010251	Middle Door Frame (5500) 中门架 (5500)	1		

3.1 Third Level Fully Free Gantry Assembly (With Side Shift) 三级全自由门架总成 (带侧移)




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
25	30221080008	Screw M8×10 紧定螺钉	2		03.02701
26	30101160024	Bolt M16×70 螺栓	1		03.0395
27	50301165005	Shaft Sleeve Φ16.5×Φ26 轴套	1		30.05.218
28	51107000008	Oil Pipe Pulley 油管滑轮	1		30.05.216
29	53101000050	Chain A (4800) 链条 A (4800)	2		02.LT.3493
29	53101000077	Chain A (5500) 链条 A (5500)	2		
30	53104000005	Bar 拉杆	4		30.05.158
31	30511030003	Pin 3×20 开口销	8		03.0557
32	50101075002	Axle Φ7.5 轴	8		03.03202
33	30511040001	Pin 4×30 开口销	6		03.0339
34	20104010205	Outer Door Frame (4800) 外门架 (4800)	1		33.042.0016
34	20104010253	Outer Door Frame (5500) 外门架 (5500)	1		
35	30201050017	Screw M5×25 螺钉	1		03.01410
36	30411050001	Spring Washer Φ5 弹垫	1		03.00132
37	20203000009	Pipe Clamp 管夹	1		30.03.005
38	30211030008	Screw M3×12 螺钉	2		03.05364
39	70109000002	Proximity Switch 近接开关	1		19.0524
40	20204001551	Installation Board 安装板	1		
41	30201060003	Screw M5×25 螺钉	2		03.1180
42	54001000015	Bushing 复合套	2		03.0981
43	30401120001	Flat Washer Φ12 平垫	2		03.00514
44	50105300007	Pin Shaft Φ30 销轴	2		33.019.0021
45	30101100003	Bolt M10×40 螺栓	4		03.0741
46	50302005003	Shim 2 垫片 2	2		30.01.0649
47	50302005002	Shim 1 垫片 1	2		30.01.0648
48	20204000288	Bending Plate 弯板	2		30.01.0650
49	54102000001	Hoop 抱箍	2		30.01.0647
50	51101000001	Roller Assembly 滚轮总成	8		


3.1	Third Level Fully Free Gantry Assembly (With Side Shift) 三级全自由门架总成 (带侧移)
-----	---

[illegible]

3.2	Tray Rack Assembly (With Side Shift) 托盘架总成 (带侧移)
-----	---


[illegible]

4.1 Body Hydraulic System 车身液压系统




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	40204000012	Oil Pipe Joint 油管接头	4		02.YYL. 3040
2	30803016001	Gasket Φ16 密封垫	9		03.0483
3	40121000117	Side Shifted Steel Pipe 侧移钢管	1		02.YYL. 3971
4	40121000119	Side Shifted Steel Pipe 侧移钢管	1		02.YYL. 3972
5	40121000115	Inclined Steel Pipe 后倾钢管	1		02.YYL. 3969
6	40121000113	Inclined Steel Pipe 前倾钢管	1		02.YYL. 3968
7	40204000024	Bolt 螺栓	2		02.YYL. 3302
8	30803022001	Gasket Φ22 密封垫	5		03.0486
9	40121000111	Lifting Steel Pipe 起升钢管	1		02.YYL. 3966
10	40204000011	Banjo Bolt 空心螺栓	2		02.01.30810
11	30803014001	Gasket Φ14 密封垫	4		03.0482
12	40206000016	Oil Return Joint 回油接头	1		02.01.9170
13	54013000004	Strong Clamp 强力卡箍	4		03.05384
14	40111300005	Return Pipe 回油管	1		02.YYL. 3746
15	40406000014	Valves 阀组	1		02.DLDY. 3461
16	20204000006	Installation Board 安装板	1		
17	30101080003	Bolt M8×20 螺栓	18		03.0357
18	30411080002	Spring Washer Φ8 弹垫	18		03.0012
19	30401080001	Flat Washer Φ8 平垫	18		03.0050
20	40121000109	Oil Outlet Steel Pipe 出油钢管	1		02.YYL. 3965
21	40201220001	Straight Joint 直接头	1		02.01.324326
22	70401000018	Ac Machine 交流电机	1		02.DJ. 00827
23	30201100025	Screw M10×40 螺钉	4		03.0168
24	30411100002	Spring Washer Φ10 弹垫	10		03.0014
25	30401100002	Flat Washer Φ10 平垫	10		03.00513
26	40206000009	Pump Joint 泵接头	1		02.01.324325
27	40111300004	Oil Suction Pipe 吸油管	1		02.YYL. 3745
28	40410000016	Fuel Cap 油箱盖	1		02.01.9175


4.1	Body Hydraulic System 车身液压系统
-----	---------------------------------

[illegible]


4.2 Three Stage Gantry Hydraulic System

[illegible]

4.3 Side Shift Hydraulic System 侧移液压系统


[illegible]

5.1 Electrical Assembly 电气总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	70601000020	Instrument 仪表	1		02.DLB.317707
2	70111000003	Operating Switch 操作开关	1		02.SB.3191
3	70105000003	Key Switch 钥匙开关	1		02.01.9237
4	70102000003	Headlight Switch 大灯开关	1		16.0319
5	70113000003	Switch Frame 开关边框	1		16.0440
6	70412020420	Charger 充电器	1		
7	70501480002	Battery 电池	1		02.XDC.3404
8	30251050015	Screw M5×12 螺钉	2		03.0083
9	70104000006	Emergency Stop 急停开关	1		02.01.2248
10	30201060037	Screw M6×16 螺钉	2		03.0934
11	70222000002	Horn 喇叭	1		02.01.2218
12	20204000009	Installation Board 安装板	1		30.51.0003
13	30251050008	Screw M5×12 螺钉	4		03.0194
14	30411050001	Spring Washer Φ5 弹垫	6		03.00132
15	30401050001	Flat Washer Φ5 平垫	4		03.00511
16	70304000001	Converter 转换器	1		02.01.21480
17	30101080003	Bolt M8×20 螺栓	5		03.0357
18	30411080002	Spring Washer Φ8 弹垫	5		03.0012
19	30401080001	Flat Washer Φ8 平垫	5		03.0050
20	70301000023	Control Board Assembly 控制板总成	1		
21	30201040012	Screw M4×6 螺钉	12		03.0127
22	54331000005	Wire Socket 线插座	6		02.01.02070
23	20201000160	Wire Connector Socket 线接头座	1		30.11.0001
24	30201050015	Screw M5×10 螺钉	2		03.0139
25	70110000001	Pedal Switch 踏板开关	1		02.01.2236
26	30301040001	Nut M4 螺母	3		03.0254
27	30411040002	Spring Washer Φ4 弹垫	3		03.0008
28	30401040005	Flat Washer Φ4 平垫	3		03.1138

5.1	Electrical Assembly 电气总成
-----	-----------------------------


[illegible]

5.2 Control Board Assembly
控制板总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	70301000023	Control Board Assembly 控制板总成	1		
1	30201060021	Screw M6×20 螺钉	18		03.0149
2	30411060002	Spring Washer Φ6 弹垫	18		03.0011
3	30401060001	Flat Washer Φ6 平垫	18		03.00512
4	70331000054	Copper Bar 铜条	1		
5	30211050003	Screw M5×12 螺钉	2		03.02261
6	30411050001	Spring Washer Φ5 弹垫	8		03.00132
7	30401050001	Flat Washer Φ5 平垫	8		03.00511
8	20203001172	Support 支架	1		30.51.0093
9	30201050014	Screw M5×35 螺钉	2		03.01340
10	70331000055	Copper Bar 铜条	1		
11	70921000001	Negative Terminal 负极接线柱	1		16.0543
12	70302000025	Ac Controller 交流控制器	2		02.KZQ.2306
13	70302000013	Dc Steering Controller 直流转向控制器	1		02.KZQ.2163
14	30201040009	Screw M4×10 螺钉	2		03.0123
15	70331000409	Electric Control Board 电控板	1		
16	70711000001	Fuse Base 保险丝底座	2		02.01.3057
17	30211040008	Screw M4×16 螺钉	2		03.02152
18	70701000004	Fuse 保险丝	2		02.01.20001
19	70331000036	Copper Bar 铜条	1		
20	30211050016	Screw M5×10 螺钉	4		03.0219
21	70303000003	Contactors 接触器	1		02.01.21620
22	70331000056	Copper Bar 铜条	1		

5.3 Wiring Harness Assembly 线束总成

[illegible]

5.4 Cable Assembly
电缆总成



Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	20104030165	Cable Assembly 动力线组件	1		
1	20104030184	Car Body Plug Wire Assembly 车体插头线材组件	1		
2	20104030185	Battery Plug Wire Assembly 电瓶插头线材组件	1		
3	20104030170	Emergency Stop - Safety Cable 急停-保险电缆线	1		
4	20104030172	Motor U-Phase Line 行走电机 U 相线	1		
5	20104030173	Motor V-Phase Line 行走电机 V 相线	1		
6	20104030174	Motor W-Phase Line 行走电机 W 相线	1		
7	20104030175	Pump Motor U-Phase Line 泵电机 U 相线	1		
8	20104030176	Pump Motor V-Phase Line 泵电机 V 相线	1		
9	20104030177	Pump Motor W-Phase Line 泵电机 W 相线	1		
10	20104030178	Steering Controller Cable+ 转向控制器正极线	1		
11	20104030179	Steering Controller Cable- 转向控制器负极线	1		
12	20104030180	Steering Motor M1 Line 转向电机 M1 线	1		
13	20104030181	Steering Motor M2 Line 转向电机 M2 线	1		
14	20104030171	Controller Cable- 控制器负极线	1		
15	20104030186	Controller Cable+ 控制器正极线	1		

零件目录最终由制造商保留解释权！

The power of interpretation of this part catalogue will be preserved by the manufacturer eventually!