




SL20ZD
Electric pallet truck
电动托盘搬运车
Parts list 零件目录

20250217 V02

PARTS ORDERING INSTRUCTIONS

HOW TO ORDER

When you order, supply the part number, quantity, model and serial numbers of your machine. Supplying this information will assure prompt, efficient handing of your order.

Since your dealer carries many parts in stock and maintains up-to-date prices on all parts, he will be able to process your order immediately. If, for some reason, the part is not in stock, he will order it from the factory. In either event, he maintains a current file of service manuals, which give all available parts ordering or technical information.

WHERE TO ORDER

Always order parts from the dealer who sold you your truck. If it is necessary for the dealer to order parts from the factory, he is able to get prompt service for you. Parts are shipped in accordance with shipping instructions given on the order.

INSTRUCTIONS FOR RETURNING PARTS

Under NO CIRCUMSTANCES will parts be accepted at the factory for credit without prior approval. We cannot accept responsibility for parts returned without authorization.

If you have some parts which must be returned, contact your dealer. If he believes parts should be returned, he will arrange for authorization to return the parts.

CHANGES

When changes are made to the machine, revised pages for this manual will be issued. These pages must be inserted in your parts manual as soon as they are received.

Failure to keep your parts manuals up to date will result in confusion and may cause you to order wrong parts.

零件订购说明

如何订购

当您订购的时候，您需要提供叉车零件的编号，数量，型号和序列号。提供这些信息能够保证您的订购更加的高效。

因为您的经销商有很多零件的存货，而且需要保持所有零件的价格是最新的，所以他会尽快地处理您的订购需求。假如因为某些原因，存货中没有这个零件，那么他会从公司订货。无论怎样的情况，他手里都会有一份服务手册文件，它能提供所有可用的零件的订购信息或者技术信息。

订购地点

当您需要订购零件时，请到销售给您叉车的经销商那里订购。如果经销商有必要从公司订购零件，他能为您提供快捷的服务。根据您的订购信息，零件和它对应的操作说明会一起装好。

零件的退还说明

一般情况下，因为信用的关系，退还的零件没有事先的同意，是不会被公司认可的。我们不会对没有经过授权但退还过来的零件负责。

如果您有一些零件一定要退还，请联系您的经销商。若经销商确认零件可以退还，则其会安排授权要退还的零件。

技术修改

当叉车技术有修改时，这本手册的修正页会重新发行。当您拿到这些修正页时，您一定要立即把它们插入到您的零件手册中。若没有及时的更新您的零件手册，则可能会导致您订购、维护等方面的错误。

GENERAL INFORMATION

INDEX

This parts manual is arranged for easy identification of parts .The index at the front of the catalog gives location of major groups and assemblies.

PART LIST

The Item, describes the item on the Figure you are looking at. The Part No. is a numerical description of the item and the part ordering number. The Description is a description of the part number in alphabetical form. The Qty is the quantity used on the machine. The Applied Date is a description when the part is applicable.The Remark is the explanation of the part for a supplement such as the model the capability, the characteristic etc.

HOW TO READ PARTS MANUAL

HELP 1:

Item	Part No	Description	Qty	Applied Date	Remark
------	---------	-------------	-----	--------------	--------

A →

1		02.XDC.3556	Battery	1		24V/20AH
1		02.XDC.3557	Battery	1		24V/30AH
1		02.XDC.3558	Battery	1		24V/40AH
2		03.0132	Screw M5×8	5		

B →

7		03.0245	Nut M12	2		
8		03.04790	Spring	2		
9	01	30.01.6685	Wheel Frame	1	-210125	
9	02	40.11.048	Wheel Frame	1	210125-	

C →

6		02.KSCX.0001	Cover	1		
7		03.0243	Nut M10	2		Cancel
8		40.11.040	Roller	2		
9		03.1088	Bolt M10×60	2		

D →

3		33.054.0001	Frame (550)	1		
3		33.054.0002	Frame (685)	1		
4		03.02393	Screw M6×16	6		
5		40.18.005	Shaft (550)	1		
5		40.15.044	Shaft (685)	1		

E →

6		33.036.0007	Push Rod Welding	2		For 1800Kg
7		03.0691	Bushing Φ19×Φ16×15	4		
8		03.0305	Round Pin Φ5×30	10		

A: The part of Index 1 is Optional.

B: The part of Index 9 has an Applicability, because it's our policy to constantly improve our products.

C: The part of Index 7 indicates that the part is canceled. Note the version number when ordering.

D: The part of Index 3 indicates that the frame welds have different specifications, 550 or 685 indicates the outer width of the forks. Index 5 indicates the parts used for the outer width of the forks.

E: The part of Index 6 indicates that the part is used for model with load capacity of 1800KG.

1. Record by time

– 210125 : Ending on January 25, 2021.


210125- : Beginning on January 25, 2021.

2. Record by serial number

01 : Ending at 01

02 : Starting at 02

HELP 2:



A:Section 5.2 is the original version.

B:Section 5.201 is the version that some parts in the Section 5.2 have been changed.

C:Section 5.202 is the version that some parts in the Section 5.201 have been changed.

When you order, Please locate specific parts information of your truck by the Applied Date of parts in each version.

概要
目录

将零件目录分组成几个易识别的部分，并把主要结构和总成放置在索引目录中。

零件明细表

Item 描述的是在插图上，您想要找的项目。**Part No.**是零件的一系列描述和它的订购号码。**Description** 是用文字的形式描述零件的号码。**Qty** 代表的是零件在叉车上使用的数量。**Applied Date** 表示的是零件适用的时间范围。**Remark** 是用来补充说明零件信息(例如车型、性能和特征等)。

怎么读取零件明目录

帮助 1:

Item 序号		Part No 代码	Description 名称		Qty 数量	Applied Date 适用日期	Remark 备注
A	⇒	1		02. XDC. 3556	Battery 锂电池	1	24V/20AH
		1		02. XDC. 3557	Battery 锂电池	1	24V/30AH
		1		02. XDC. 3558	Battery 锂电池	1	24V/40AH
		2		03. 0132	Screw M5×8 螺钉	5	
B	⇒	7		03. 0245	Nut M12 螺母	2	
		8		03. 04790	Spring 弹簧	2	
		9	01	30. 01. 6685	Wheel Frame 轮架	1	-210125
		9	02	40. 11. 048	Wheel Frame 轮架	1	210125-
C	⇒	6		02. KSCX. 0001	Cover 前盖板	1	
		7		03. 0243	Nut M10 螺母	2	Cancel/取消
		8		40. 11. 040	Roller 滚子	2	
		9		03. 1088	Bolt M10×60 螺栓	2	
D	⇒	3		33. 054. 0001	Frame (550) 车架	1	
		3		33. 054. 0002	Frame (685) 车架	1	
		4		03. 02393	Screw M6×16 螺钉	6	
		5		40. 18. 005	Shaft (550) 支撑轴	1	
		5		40. 15. 044	Shaft (685) 支撑轴	1	
E	⇒	6		33. 036. 0007	Push Rod Welding 推杆	2	For 1800Kg
		7		03. 0691	BushingΦ19×Φ16×15 复合套	4	
		8		03. 0305	Round PinΦ5×30 弹性圆柱销	10	

A: 序号 1 表示该零件有几个品种可供您的选择。

B: 序号 9 表示该零件有一个适用的时间范围。这是因为我们在不断地进行产品的升级。

C: 序号 7 表示该零件取消，订购时注意版本号。

D: 序号 3 表示车架焊接体有不同的规格，550 或 685 表示货叉的外宽。序号 5 表示配用于货叉外宽的零部件。

E: 序号 6 表示该零件配用载重 1800KG 车型。

1. 用时间记录

– **210125** : 截止到 2021 年 01 月 25 日


210125- : 起始于 2021 年 01 月 25 日

2. 用序列号记录

01 : 截止序列号 01

02 : 起始序列号 02

帮助 2:



A: 章节 5.2 表示原始版本；

B: 章节 5.201 表示在原始版本（章节 5.2）上零件有所变更；

C: 章节 5.202 表示在变更版本（章节 5.201）上零件有所变更。

当您订购零件时，请根据每个版本中零件的适用时间来判断您所选购车型的零件信息。

Index 目录

1 Body System 车身系统

1.1 Fork Carriage System 叉架系统.....	错误！未定义书签。
1.2 Main Frame Assembly 车架总成.....	2
1.3 Connecting Rod Components 连杆组件.....	4
1.4 Balance Wheel Assembly 平衡轮组件.....	5
1.5 Pedal Components 踏板组件.....	6
1.6 Housing Assembly 外罩总成.....	7

2 Drive System 驱动系统

2.1 Drive Assembly 驱动总成.....	8
------------------------------	---

3 Operating System 操纵系统

3.101 Operating System 操纵系统.....	10
3.2 Handle Head Assembly 手柄头总成.....	11


4 Hydraulic System 液压系统

4.1 Hydraulic System 液压系统.....	13
--------------------------------	----


4.2 Hydraulic Pump Assembly 动力单元.....	14
5 Electrical System 电气系统	
5.1 Electrical System 电气系统.....	15
5.2 Electronic Components (1232) 电控组件 (1232)	16
5.3 Wiring Harness Assembly 线束总成.....	错误！未定义书签。
5.4 Cable Assembly (Lead Acid Battery) 电缆总成 (铅酸电池)	18
5.5 Cable Assembly (Lithium battery) 电缆总成 (锂电池)	19

修订记录

版 本	修订人	更改编号	修订事项
20240715 V01	莫敏萍		首次发布；
20250217 V02	朱阳敏	NO. 2025041	①：3.101 代码 20301010585 转向感应器组件更改为 20301010002 转向感应器组件。


1.1 Fork Carriage System 叉架系统							
		Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
		1	30101160017	Set Bolt M16×55 螺栓	1		03.0394
		2	30301160002	Nut M16 螺母	1		03.0260
		3	30411160002	Spring Washer Φ16 弹垫	1		03.0017
		4	30401160002	Flat Washer Φ16 平垫	1		03.0047
		5	20101010407	Fork 叉架 540	1		
		5	20101010401	Fork 叉架 685	1		
		6	50402000006	Pullback spring 拉簧	1		03.0896
		7	20101010148	Stop plate 限位板	1		33.035.0007
		8	30201080022	Screw M8×20 螺钉	2		03.0817
		9	51103000061	Roller assembly 滚轮组件	4		02.01.3068
		10	51103000022	Regulating screw 调节螺丝	4		02.01.30683
		11	51103000023	Release plate 止松片	4		
		12	51102000001	Idler wheel 滚轮	4		02.01.3071
		13	30421350001	Cir clip For Shaft Φ35 轴用挡圈	4		03.0583
		14	51103000024	Holder 支架	4		02.01.30681
		15	51103000025	Dustproof gasket 防尘片	4		02.01.30682
		16	20201000669	Front panel 前封板	1		30.01.6376
		17	30251080029	Screw M8×16 螺钉	4		03.0116

1.2 Main Frame Assembly
车架总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	20101010392	Frame (540) 车架 (540)	1		
1	20101010393	Frame (685) 车架 (685)	1		
2	56008000001	Strong magnet 强磁	2		19.1351
3	20101010397	Mini clamshell 小翻盖	1		
4	50201100004	Clamp screw 卡位螺钉	2		03.0593
5	20101010399	Panel 面板	1		
6	30251060029	Screw M6×16 螺钉	6		03.0089
7	30351060005	Nut M6 卡扣螺母	2		03.0587
8	20201001962	Upper cover plate 上盖板	1		
9	30251060025	Screw M6×12 螺钉	4		03.0090
10	30201050011	Screw M5×16 螺钉	2		03.0133
11	30411050001	Spring Washer Φ5 弹垫	2		03.00132
12	30401050001	Flat Washer Φ5 平垫	2		03.00511
13	20201001946	Latch fixing plate 插销固定板	1		
14	50401000072	Spring 弹簧	1		
15	20201001903	Plug 插销	1		
16	30501050008	Round Pin Φ5×30 弹性圆柱销	1		03.0305
17	20101010402	Battery gate 电池门	1		
18	20206000203	Battery baffle 电瓶挡板	1		30.34.0014
19	30411080002	Spring Washer Φ8 弹垫	8		03.0012
20	30301080001	Nut M8 螺母	2		03.0258
21	54316000001	Shock Pad 减震垫	2		02.01.2315
22	20201001941	Pulley bottom 滑轮底板	2		
23	30201080024	Screw M8×25 螺钉	8		03.01562
24	51108000008	Roller 辊筒	5		30.01.6610
25	30201080007	Screw M8×40 螺钉	6		03.1099
26	30401080001	Flat Washer Φ8 平垫	6		03.00512

1.2	Main Frame Assembly 车架总成
-----	-----------------------------


[illegible]

1.3 Connecting Rod Components 连杆组件




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	20301010583	Connecting Rod Components 连杆组件	2		
1	54001000009	Bushing $\Phi 23 \times \Phi 20 \times 16.5$ 带肩复合套	8		03.0453
2	51251000014	Connecting Plate 连板	4		30.01.1290
3	30701020007	Bearing 轴承	8		03.90.057
4	51241000019	wheels 轮子	4		02.LZ.0119
5	50101200040	Front Shaft 前轮轴	4		30.01.3459
6	30501050003	Round Pin $\Phi 5 \times 35$ 弹性圆柱销	10		03.0303
7	55103000013	Block 力臂块	2		
8	54002000016	Bushing $\Phi 17 \times \Phi 19 \times 12$ 复合套	4		03.0460
9	50101170006	Shaft 推杆轴	2		30.01.11871
10	30501050008	Round Pin $\Phi 5 \times 30$ 弹性圆柱销	2		03.0305
11	55501000104	Push Rod 推杆	2		
12	54002000023	Bushing $\Phi 20 \times \Phi 23 \times 20$ 复合套	4		03.0450
13	50105200010	Shaft 力臂架短轴	4		33.025.0015
14	30401080001	Flat Washer $\Phi 8$ 平垫	4		03.0050
15	30411080002	Spring Washer $\Phi 8$ 弹垫	4		03.0012
16	30101080003	Set Bolt $M8 \times 20$ 螺栓	4		03.0357
17	51108000035	Rushing 滚子	2		30.22.0004
18	55101000002	Bracket 力臂架	2		30.16.0038
19	50105200016	Shaft 力臂架轴	2		
20	30201080022	Screw $M8 \times 20$ 螺钉	2		03.0817
21	20201000531	Exit roller 退出滚子	2		30.01.1814
22	50101200059	Shaft 力臂块轴	2		30.22.0002
23	20301020905	Twin Wheel Frames 双轮连杆轮架	2		


1.4 Balance Wheel Assembly

[illegible]


1.5	Pedal Components 踏板组件
-----	--------------------------

[illegible]

1.6	Housing Assembly 外罩总成
-----	--------------------------


[illegible]

2.1 Drive Assembly
驱动总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	20301010577	Driving Assembly 驱动总成	1		
1	55704000007	Electromagnetic brake 电磁制动器	1		02.01.0053
2	70401000006	Ac drive motor 交流驱动电机	1		02.DJ.0081
3	30201080004	Screw M8×20 螺钉	8		03.01550
4	30411080002	Spring Washer Φ8 弹垫	24		03.0012
5	30101140007	Set Bolt M14×50 螺栓	5		03.0780
6	30411140002	Spring Washer Φ14 弹垫	5		03.0016
7	30401140003	Flat Washer Φ14 平垫	5		03.0045
8	20201001388	Driving base plate 驱动底板	1		
9	70309000009	Encoder 编码器	1		02.BMQ.2138
10	73109000014	Small Magnetic Head 小磁头	1		02.01.2152
11	70402000001	Steering motor 转向电机	1		02.DJ.2102
12	30201080022	Screw M8×20 螺钉	4		03.0817
13	52105000053	Steering motor pinion 转向电机小齿轮	1		
14	30401060006	Large washer Φ6 大垫圈	1		03.0644
15	30411060002	Spring Washer Φ6 弹垫	1		03.0011
16	30201060020	Screw M6×16 螺钉	1		03.0147
17	70109000000	Proximity switch 接近开关	1		19.034653
18	30211040007	Screw M4×8 螺钉	2		03.02150
19	30411040002	Spring Washer Φ4 弹垫	2		03.0008
20	30401040005	Flat Washer Φ4 平垫	2		03.1138
21	20203000664	Mounting sleeve 安装套	1		57700001060
22	51241000021	wheels 轮子	1		02.LZ.0121
23	30351140001	Nut M14×1.5 螺母	6		03.02020
24	52105000023	Output shaft 输出轴	1		02.01.9083
25	30802065002	oil seal 油封	1		02.01.9086
26	30702050003	Bearing 轴承	1		03.90.059

2.1 Drive Assembly
驱动总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
27	50204160003	Oil plug 油塞	1		02.01.9088
28	30803016001	Washer 组合密封垫	1		03.0483
29	30201080007	Screw M8×40 螺钉	8		03.01590
30	52105000050	Gearbox 齿轮箱体	1		
31	30702060001	Bearing 轴承	1		03.90.060
32	52105000020	Arc gears 立式驱动弧齿	1		02.01.9080
33	50203300001	Nut M30×1.5 螺母	1		02.01.00801
34	52105000019	Shell cover 壳体盖	1		02.01.9079
35	50204140003	Oil plug 油塞	1		02.01.9089
36	30251080012	Screw M8×16 螺钉	8		03.0117
37	30601080003	Flat key 平键	1		02.01.9087
38	30702025001	Bearing 轴承	2		03.90.035
39	52105000043	Big helical gear 大斜齿	1		02.01.9081
40	50205200001	Nut M20×1.5 螺帽	1		02.01.9090
41	52105000024	Gear wheel 齿轮	1		02.01.9084
42	20201000508	Stripe induction strip 条状感应条	1		
43	30211040019	Screw M4×10 螺钉	3		03.04170
44	30201080005	Screw M8×25 螺钉	4		03.01560
45	30711160001	Bearing 轴承	1		02.01.0071
46	30201080032	Screw M8×35 螺钉	8		03.0158

3.101	Operating System 操作系统
-------	--------------------------


[illegible]

3.2 Handle head assembly 手柄头总成




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	71501000001	Handle head assembly 手柄头总成	1		02. SB. 317515
1	71511000015	Belly Switch 肚皮开关	1		16. 0038
2	71511000016	Spring 弹簧	1		03. 0725
3	71511000001	Upper Cover 上盖	1		02. 01. 31770
4	71511000014	Button Plug 按钮堵头	4		02. 01. 317725
5	70103000006	Micro Switch 微动开关	7		
6	71511000007	Lift Button Base 升降按钮底座	2		02. 01. 317718
7	71511000004	Lift Button 升降按钮	2		02. 01. 317721
8	71511000017	Cylindrical Pin $\Phi 3 \times 17$ 圆柱销	2		03. 0760
9	73109000011	Fixing Sleeve 固定套	2		30. 01. 3427
10	71511000018	Spring 弹簧	3		03. 0726
11	71511000005	Horn Button 喇叭按钮	1		02. 01. 317723
12	71511000345	Button Clip 按钮卡子	2		02. 01. 317724
13	30231030002	Screw 螺钉	5		02. SB. PJ. 0012
14	71511000107	Install The Card 安装卡	1		02. SB. PJ. 0006
15	70132000105	Accelerator Assembly 加速器总成	1		02. 01. 2155
16	71511000115	Knob 旋钮	2		02. SB. PJ. 0027
17	71511000013	Bracket Right 支架右	1		30. 01. 3424
18	70132000001	Accelerator 加速器	1		02. 01. 2151
19	30431080001	Wave Washers 波形垫圈	2		03. 0735
20	71511000012	Bracket Left 支架左	1		30. 01. 3423
21	71511000112	Shaft Sleeve 轴内套	2		30. 01. 3426
22	71511000113	Shaft Jacket 轴外套	2		02. SB. PJ. 0025
23	30211030008	Screw M3 $\times$ 12 螺钉	2		03. 05364
24	30201050009	Screw M5 $\times$ 12 螺钉	2		03. 0131
25	71511000002	Lower Cover 下盖	1		02. 01. 31772
26	30201050017	Screw M5 $\times$ 25 螺钉	2		03. 01410


3.2	Handle head assembly 手柄头总成
-----	-------------------------------

[illegible]

4.1	Hydraulic System 液压系统
-----	--------------------------


[illegible]

4.2 Hydraulic Pump Assembly
动力单元




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
A	40401024023	Hydraulic Pump Assembly 动力单元	1		02.DLDY.01171
1	20101030752	Cable 接触器连接线	1		
2	70402000007	Motor 直流提升电机	1		02.DJ.33618
3	54312000003	Cover 烟斗护套	2		02.01.2265
4	70303000006	Relay Starter 直流接触器	1		02.01.2207
5	54012000012	Clamp 抱箍	2		03.1045
6	40411000027	Coupling 联轴器	1		02.01.9308
7	40407000006	Adapter 中心块	1		02.01.9309
8	40405000038	Check Valve 单向阀	1		02.01.9028
9	71531000003	Valve Element 电磁阀	1		02.01.9150
10	71531000031	Electromagnet 电磁阀线圈	1		02.01.9366
11	40405000056	Relief Valve 溢流阀	1		02.01.9151
12	40405000006	Pressure Valve 压力补偿阀	1		02.01.9385
13	30801067001	O-ring 0型圈	1		02.01.9317
14	30801017001	O-ring 0型圈	1		02.01.9157
15	40402000006	Gear Pumps 齿轮泵	1		02.01.9059
16	30201050020	Screw M5×65 螺钉	2		03.0967
17	30411050001	Gas Spring Φ5 弹垫	6		03.00132
18	40411000060	Right Angle Joints 直角管	1		02.01.0340
19	40412000005	Filter 滤网	1		02.01.9310
20	40410000010	Cover 油箱盖	1		02.01.30423
21	40409000002	Tank 油箱	1		02.01.9311
22	30401050001	Flat Washer Φ5 平垫	4		03.00511
23	30101050010	Bolt M5×12 螺栓	4		03.0911

5.1 Electric System
电气系统




Item 序号	Part No. 代码	Description 名称	Qty 数量	Applied Date 适用日期	Remark 备注
1	30201080022	Screw M8×20 螺钉	4		03.0817
2	70301000011	Ac electronic control 交流电控	1		74700000073
3	70105000001	Key switch 钥匙开关	1		02.01.2186
4	30251050016	Screw M5×16 螺钉	2		03.0085
5	70104000005	Stop Switch 急停开关	1		
6	70601000006	Electricity Meter 电量表	1		
7	30401060001	Flat Washer Φ6 平垫	2		03.00512
8	30411060002	Spring Washer Φ6 弹垫	2		03.0011
9	30201060023	Screw M6×30 螺钉	2		03.0151
10	30201040016	Screw M4×8 螺钉	15		03.0144
11	30411040002	Spring Washer Φ4 弹垫	17		03.0008
12	30401040005	Flat Washer Φ4 平垫	12		03.1138
13	70110000001	Foot pedal 脚踏开关	1		02.01.2236
14	54331000005	Wire 线叉座	6		02.01.02070
15	30201050007	Screw M5×12 螺钉	2		03.1087
16	20201000160	Connector seat 线接头座	1		30.11.0001
17	70501240007	Cell 电池	1		02.XDC.219201
18	54101000006	Jockey card 骑马卡 10	2		03.04611
19	30201060038	Screw M6×12 螺钉	4		03.1231
20	70103000001	Micro Switch 微动开关	1		02.01.2182
21	54305000002	Switch Box 开关盒	1		
22	30211040011	Screw M4×25 螺钉	2		03.0223
23	70331000412	Electric control board 电控板	1		20202001692
24	70302000011	Steering controller 转向控制器	1		02.KZQ.2369
25	30201040011	Screw M4×30 螺钉	2		03.0125

5.2	Electronic Components (1232)
	电控组件 (1232)


[illegible]

5.3 Wiring Harness Assembly (1232)


线束总成 (1232)

[illegible]

5.4	Cable Assembly (Lead Acid Battery) 电缆总成 (铅酸电池)
-----	---

[illegible]

5.5	Cable Assembly (Lithium battery) 电缆总成(锂电)
-----	--

[illegible]

本零件目录最终由制造商保留解释权

The power of interpretation of this part catalogue will be preserved by the manufacturer eventually!